


Part No. 8185900

# CONTROL PANEL PARTS

For Models: RS610PXGW8, RS610PXGV8  
(White) (Black on Biscuit)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4456313	Control Panel Assy. W/Membrane Switch
	4449745	Screw
	3400832	Screw
2	4451034	Gasket, Control Panel
3	4452892	Microcomputer
	4449745	Screw

# OVEN PARTS

For Models: RS610PXGW8, RS610PXGV8  
(White) (Black on Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models:RS610PXGW8, RS610PXGV8  
(White) (Black on Biscuit)

Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1		Trim, Side
	4450844	RH Black
	8281236	LH Black
	4449747	Screw
3		Hinge Receiver
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
7	4455286	Top, Chassis
	4449809	Screw
9	4452159	Tube, Vent
	3196176	Screw
10	4451664	Fan & Bracket Assy
	4449809	Screw
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
13	4452165	Lens, Light


Illus. No.	Part No.	DESCRIPTION
14	4455612	Frame, Front
	4449040	Screw
	4450118	Nut
15	4450493	Gasket, Door
19	4451478	Support, Insulation
	4449809	Screw
21		Rail, Side
	4450579	Right Side
	4450580	Left Side
	4448444	Grommet
	4449154	Screw
23	4450051	Deflector
	4449154	Screw
25	4455641	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452234	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)

Illus. No.	Part No.	DESCRIPTION
29	4455636	Sensor
	4449154	Screw
37	4451354	Fuse – Thermal
	4449809	Screw
43	4455530	Base, Chassis
49	4448933	Retainer
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
51	4448477	Trim, Bottom
53	4449845	Support, Bracket
	4449154	Screw
<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
<b><u>INSULATION</u></b>		
	4449316	Insulation, Wrap
	4450365	Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN DOOR PARTS

For Models: RS610PXGW8, RS610PXGV8  
(White) (Black on Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4455618	Door Liner
2	4449259	Glass, Inner
3		Hinge, Door
	8300567	R.Side
	8300568	L.Side
	4449743	Screw (4)
4	8300778	Retainer, Glass
	4449809	Screw (4)
5	4450813	Bracket, Handle
	4451040	Screw (4)
	4449743	Screw (2)
6	8300820	Seal, Top
8	4452065	Assy, Door Glass
9	4448854	Handle, Door
10	4450863	Retainer, Glass
	4449743	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models: RS610PXGW8, RS610PXGV8  
(White) (Black on Biscuit)




Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models: RS610PXGW8, RS610PXGV8  
(White) (Black on Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw
2	4454943	Plate, Mounting
11	4449868	Block, Terminal
	3400080	Screw
	112432	Nut
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Compt.
	3191832	Right
	3191833	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
16	3191842	Cover, Rear
	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models:RS610PXGW8, RS610PXGV8  
(White) (Black on Biscuit)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## PAINT, TOUCH-UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black

## PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black

## ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## SPLICING WIRES---25FT.

### LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## WIRING HARNESS PARTS

4449809	Screw
3191220	Harness, Wire (Main)
8301750	Harness, Wire (EDC)
4451163	Conduit
3400015	Screw, Ground
4448664	Clamp
3192236	Harness, Wire (Infinite Switch)
4455592	Harness, Wire (Light)
4454384	Ground, Wire
4452222	Spacer, Harness
4454835	Tie, Cable

## Miscellaneous

4448950	Screw, Install. 8-14 x 1" (4)
814381	Hinge Pin Kit